
Meridian 1

Carrier Remote IPE

Description, installation, and maintenance

Document Number: 553-3001-021

Document Release: Standard 3.00

Date: October 1997

© 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

September 1995

Standard, release 1.00. Initial release.

August 1996

Standard, release 2.00. This document is reissued to incorporate cabling changes and addition of wiring diagrams in Appendix C.

October 1997

Standard, release 3.00. This document is reissued to include editorial changes.

Contents

About this document	1
References	2
Carrier Remote IPE product description	3
System overview	3
System description	4
Carrier Remote IPE physical architecture	4
Carrier Remote IPE functional architecture	16
Functional description	21
Local Carrier Interface card	23
Remote Carrier Interface card	27
Engineering guidelines	33
Carrier Remote IPE capacity	33
Traffic engineering	37
System planning and ordering	45
System selection	45
Carrier Remote IPE site planning	46
Equipment installation and configuration	51
Quick reference to system installation and configuration	51
Installation overview	55
Preinstallation preparation	57
Preparing the site	57
Unpacking and inspection	58
Taking inventory	58

Routing carrier links to the Carrier Remote IPE site	59
Selecting the Local Carrier Interface card slot	60
Selecting the I/O Panel connector cutouts to install the Carrier I/O panel assemblies	61
Carrier Remote IPE connection record label	64
Meridian 1 equipment installation	66
Installing and verifying system operation	66
Installing the Local Carrier Interface card	67
Installing the Local Carrier Interface cable assemblies	71
Installing SDI and local MMI terminal cables	76
Connecting the system monitor cables	85
Connecting the carrier link to the Meridian 1	89
Carrier installation into NT and XT systems	91
Installing carrier equipment and verifying system operation	91
Installing the Local Carrier Interface card	92
Installing Local Carrier Interface faceplate cables	94
Installing SDI and MMI terminal cables	96
Connecting carrier links to the NT/XT system cabinet	102
Carrier Remote IPE column installation	103
Installing the Carrier Remote IPE column	103
Installing cards into the Remote IPE module	104
Installing the backplane cable assemblies	109
Installing system monitor cables	113
Installing remote MMI terminal cables	114
Connecting the carrier link to the Remote IPE module	115
Carrier Remote IPE cabinet installation	117
Installing the Carrier Remote IPE cabinet	117
Removing the fiber I/O bracket assembly	121
Installing the NT7R94AA Remote Cabinet Cable Assembly	122
Installing cards into the Carrier Remote IPE cabinet	124
Connecting carrier links to the Carrier Remote IPE cabinet	125
Connecting remote MMI terminal and subscriber loop cables	128
Connecting the attendant to the Carrier Remote IPE cabinet	131
Connecting the PFTU to the Carrier Remote IPE cabinet	131
Configuring the Carrier Remote IPE	133
Configuring the carrier interface cards	133

Configuring the remote MMI terminal port	138
Configuring the carriers	141
Verifying carrier link connections at the remote site	147
Carrier Remote IPE acceptance testing	153
Overview	153
Checking the system	154
Setting up test conditions	155
Performing acceptance testing	155
Voice calls	156
Data calls	158
Checking the MMI terminal operation	159
Checking carrier link protection switching	159
Removing the test setup	161
Generating traffic reports	161
Carrier Remote IPE maintenance	163
Maintenance overview	163
Diagnostic tools	164
Hardware diagnostic tools	164
Software diagnostic tools	170
Using system maintenance programs	178
Logging in on the maintenance terminal	178
Accessing the program	178
Responding to error messages	179
Exiting the program	179
Logging out	179
Logging in and using a maintenance telephone	179
Isolating and correcting faults	181
Type of faults	181
Fault isolation steps	182
System fault isolation and correction	183
Carrier Remote IPE fault isolation and correction	185
Local Carrier Interface card fault isolation and correction	187
Remote Carrier Interface card fault isolation and correction	194

Fault isolation and correction using MMI maintenance commands	198
Replacing Carrier Remote IPE cards	204
Unpacking replacement cards	204
Removing and replacing a card	204
Reinstalling covers	207
Packing and shipping defective cards	207

Appendix A: System messages 209

Appendix B: Regulatory approvals 215

Regulatory notices	216
Notice for United States Installations	216
Network connection information	218
Notice for Canadian Installations	219

**Appendix C: Connection diagrams and
external connectors pin assignment 221**

List of figures

Figure 1	
Meridian 1 to Remote IPE links	11
Figure 2	
Carrier Remote IPE column	13
Figure 3	
Carrier Remote IPE cabinet	15
Figure 4	
System functional architecture	17
Figure 5	
Meridian 1 Carrier Remote architecture	22
Figure 6	
Local Carrier Interface card functional block diagram	24
Figure 7	
Remote Carrier Interface card functional block diagram	29
Figure 8	
Carrier Remote IPE Connection Record label	65
Figure 9	
Local Carrier Interface card DIP-switch positions and function	69
Figure 10	
Local Carrier Interface card faceplate cable connections in Meridian 1	73
Figure 11	
System monitor, local MMI terminal, and carrier links cable connections	77
Figure 12	
Daisy-chaining multiple Local Carrier Interface cards	84

Figure 13	
System monitor connections at Meridian 1 and the Carrier Remote IPE	88
Figure 14	
Local Carrier Interface card faceplate cable connections in NT or XT system	93
Figure 15	
Remote Carrier Interface card DIP-switch locations and functions	107
Figure 16	
Backplane to I/O panel connections on the IPE module	112
Figure 17	
Carrier Remote IPE cabinet	120
Figure 18	
Carrier cable routing for the Carrier Remote IPE cabinet	123
Figure 19	
Carrier cable routing for the Carrier Remote IPE cabinet	127
Figure 20	
TTY and subscriber loop cable connections	130
Figure 21	
Connecting the PFTU to the Carrier Remote IPE cabinet	132
Figure 22	
TTY or terminal modes at the local and the remote sites	140
Figure 23	
NT7R51 Local Carrier Interface card	166
Figure 24	
Remote Carrier Interface card	168
Figure 25	
Loopback path for XCON test 6	192
Figure 26	
Loopback path for XCON test 7	196
Figure 27	
Single LCI connection diagram (local site connections)	222

Figure 28	
Multiple LCIs connection diagram (local site daisy-chain connection)	223
Figure 29	
Remote Carrier IPE IPE module connection diagram (single RCI configuration)	224
Figure 30	
Remote Carrier IPE cabinet connection diagram (single RCI configuration)	225
Figure 31	
Local site system monitor connection diagram (single and multiple LCI configuration)	226
Figure 32	
RJ48-type 8-pin modular plug pin assignments	234

List of tables

Table 1	
Local site carrier hardware list	5
Table 2	
Remote Carrier IPE module hardware list	7
Table 3	
Carrier Remote IPE wall-mounted cabinet hardware list	8
Table 4	
Carrier capacity calculations	37
Table 5	
Environmental requirements	47
Table 6	
LCI and RCI power requirements	48
Table 7	
Planning form	49
Table 8	
Meridian 1 modules supporting Local Carrier Interface cards	60
Table 9	
System cabinet shelves supporting Local Carrier Interface cards	61
Table 10	
Local Carrier Interface standard (default) switch settings	68
Table 11	
NT7R51 Local Carrier Interface card maintenance daisy-chain address	70
Table 12	
Remote Carrier Interface standard (default) switch settings	106

Table 13	
NT7R52 Remote Carrier Interface card system	
monitor address selection	108
Table 14	
NTAK04 AC/DC and NTAK05 DC power supply switch settings . .	118
Table 15	
MMI commands used in setting the carrier parameters	144
Table 16	
System carrier superloop maintenance commands	174
Table 17	
System carrier test command in LD 45	175
Table 18	
MMI commands	176
Table 19	
Keyboard to keypad translation table	180
Table 20	
System common and network equipment problems	184
Table 21	
Carrier Remote IPE equipment problems	185
Table 22	
System error messages related to the CRI	209
Table 23	
Remote Carrier Interface HEX error codes for self-test	213
Table 24	
Carrier Remote IPE network interfaces	218
Table 25	
8-pin modular jack pin assignment for all carrier connections	227
Table 26	
NT7R58AA Maintenance Panel 6-pin modular jack system monitor pin	
assignment for J5 and J6 connectors	228

Table 27	
NT7R58AA Local Maintenance Panel maintenance DCE port DB-9F and NT7R67DA External Maintenance Cable assembly connector pin assignment for P1 DB-9M, P2 DB-9M, and P3 DB-9F connectors . .	229
Table 28	
NT7R61 Remote Maintenance Panel maintenance port DB-9 male connector pin assignment	230
Table 29	
NT7R60AA Carrier/Alarm Panel DB-15 HD alarm connector pin assignment for Carrier Remote IPE module	231
Table 30	
NT7R60AA Carrier/Alarm Panel DB-15 HD alarm connector pin assignment for Carrier Remote IPE cabinet	232
Table 31	
Local and Remote Carrier IPE to CSU cable (NT7R87AA) pin assignment	233